



# STORAGE INFORMATION DEGASING CAPS

Version: 23. March 2021



Blue degasing cap in comparison to a general green cap.

## Gasing issue

A few of our products such as PLATUNA® N 1 Initial Concentrate and PLATUNA® N 1 Replenisher Solution, have a tendency of expanding (gasing out inside the bottle while storage).

During the past we have tried several ways in our laboratories and production to overcome this expansion problem while storage. Unfortunately, we cannot stop it completely without getting other unwanted effects.

## Significant reduction of expansion possible

We can reduce this expansion phenomena significantly by observing the following two points during storage:

1. Cool storage temperature of maximum 20 degree C
2. Applying a blue degasing cap while storage time (this will avoid that the bottle is expanding / gets damaged)

Due to air freight regulations, the bottles are delivered with green caps. It is necessary to change it to the blue caps for storage.

**Umicore Galvanotechnik GmbH**

Klarenbergstrasse 53-79  
73525 Schwaebisch Gmuend  
Germany

Phone: +49 7171 607 01

Fax: +49 7171 607 316  
[galvano@eu.umicore.com](mailto:galvano@eu.umicore.com)

[www.ep.umicore.com](http://www.ep.umicore.com)

  
**umicore**  
Electroplating